

ANWENDUNGSÜBERSICHT MACPHERSON FEDERBEINSPANNER

					
Jahr	Front	Nr.	Heck	Nr.	
Alfa Romeo					
147	00 → 07	90	50 / 11	140	10 / 111
147	07 → 10	90	50 / 11	120	10 / 111
155	91 → 12/97	180	20 / V	125	10 / 111
156	97 → 09/05	90	50 / 11	150	20 / V
156	02 → 05/06	90	50 / 11	120	20 / V
159	05 → 11	130	10 / 111	100	10 / 111
166	97 → 07	125	10 / 111	120	10 / 111
Brera	05 →	130	10 / 111	100	10 / 111
GT	03 → 10	90-120	50 / 11	120	10 / 111
GTV	95 →	180	20 / V	120	10 / 111
Guiliotta	10 →	152	20 / V	131	10 / 111
Mito	08 →	136	10 / 111	122	10 / 111
Spider	06 →	130	10 / 111	100	10 / 111
Audi					
A1	10 →	141	10 / 111	102	10 / 111
A2	99 → 08/05	130	10 / 111	100	10 / 111
A3	96 → 12	140	10 / 111	120	10 / 111
A3	13 →	130	10 / 111	132	10 / 111
A3 Cabriolet	04/08 →	148	20 / V	120	10 / 111
A4	95 → 07	130	10 / 111	130	10 / 111
A4	08 →	130	10 / 111	130	10 / 111
A4 S-line	01 → 08	135	10 / 111	109-136	10/60/111/X
A5	07 →	140	10 / 111	118	10 / 111
A6	05 → 11	135	10 / 111	130	10 / 111
A8	94 → 02	140	10 / 111	130	10 / 111
Q5	08 →	141	10 / 111	120	10 / 111
Q7	06 →	119	10 / 111	119	10 / 111
S6	→ 93	190	20 / V	111	50 / 11
TT Coupe	98 →	145	30 / IV	100	50 / 11
BMW					
1-serie E81-E82	07 →	141	30 / IV	100	50 / 11
1-serie E87	04 → 12	144	30 / IV	100	50 / 11
1-serie F20	11 →	158	20 / V	90	50 / 11
3-serie E46	00 → 06	170	20/70 / V/XI	145	30 / IV
3-serie E90	05 → 12	150	20/70 / V/XI	100	10 / 111
3-serie E91/92/93	05 → 12	150	20/70 / V/XI	100	10 / 111
5-serie E39	96 → 04	170	20/70 / V/XI	110	10 / 111
5-serie E60	04 → 10	150	20/70 / V/XI	120	10 / 111
5-serie E61	04 → 10	150	20/70 / V/XI	-	Luftfederung
5-serie F10	10 →	150	20 / V	120	10 / 111
5-serie F11	10 →	114	10/111	-	Luftfederung
6-serie E63	04 → 10	161	20 / V	100-111	10/60/111/X
6-serie E64	04 → 10	170	20 / V	80	10 / 111
X1 E84	09 →	147	30 / IV	100	10 / 111
X3 E83	04 → 10	180	20 / V	140	10 / 111
X5 E53	00 → 07	180	20 / V	125	10 / 111
X5 E70	07 → 12	126	10 / 111	134	10 / 111
Z3 E36	95 →	160	20 / V	140	10 / 111
Z4 E85	02 → 09	170	20 / V	130	10 / 111
Z4 E89	09 →	170	20 / V	130	10 / 111
Cadillac					
BLS	06 → 09	150	20 / V	141	10 / 111
Chevrolet					
Aveo T250/T255	05 → 11	145	30 / IV	120	10 / 111
Aveo T300	3/11 →	145	30 / IV	123	10 / 111
Captiva	06 → 11	155	20 / V	130	10 / 111
Cruze	09 → 14	160	20 / V	138	10 / 111
Epica	06 → 11	170	20 / V	120	10 / 111
Kalos	05 → 08	145	20 / V	125	10 / 111
Lacetti	05 → 10	155	20 / V	145	30 / IV
Lanos	03 →	141	10 / 111	161	20 / V
Matis	05 → 10	145	30 / IV	125	10 / 111
Niva	02 →	121	10 / 111	129	10 / 111
Nubria	05 → 10	155	20 / V	145	10 / 111

					
Jahr	Front	Nr.	Heck	Nr.	
Chrysler					
Orlando	11 →	165	20 / V	143	30 / IV
Rezzo	05 → 07	150	20 / V	139	10 / 111
Spark	10 →	123	10 / 111	121	10 / 111
Tacuma	05 → 07	150	20 / V	140	10 / 111
Citroën					
Berlingo	96 → 08	160	20 / V	-	Torsionsfeder
Berlingo B9	08 →	165	20 / V	131	10 / 111
C1	05 →	130	10 / 111	120	10 / 111
C2	03 → 10	144	30 / IV	110	10 / 111
C3	02 →	143	30 / IV	120	10 / 111
C4	04 → 10	170	20 / V	120	10 / 111
C4	09 →	165	20 / V	108	10 / 111
C4 Picasso	07 → 13	165	20 / V	130	10 / 111
Grand C4 Picasso	07 → 13	150	20 / V	130	10 / 111
C5 Dynamic	08 →	140	10 / 111	110	10 / 111
C8	02 → 10	180	20 / V	130	10 / 111
C 15	84 → 06	160	20 / V	110	100 / VIII/IX
C-Crosser	07 →	176	20 / V	117	10 / 111
Dispatch	96 →	181	20 / V	139	30 / IV
DS 3	09 →	150	20 / V	108	10 / 111
DS4	11 →	154	20 / V	112	10 / 111
Xsara Picasso	99 → 07	160	20 / V	-	Torsionsfeder
Dacia					
Duster	10 →	138	10 / 111	138	10 / 111
Logan	04 →	146	30 / IV	100	10 / 111
Sandero	08 →	132	10 / 111	103	10 / 111
Sandero 1,5 dCi	08 →	147	20 / V	103	10 / 111
Daewoo					
Evanda	03 →	170	20 / V	120	10 / 111
Leganza	96 →	126/170	20/60 / V/X	150	20 / V
Matiz	97 →	100	10 / 111	120	10 / 111
Nubia	96 → 03	140	10 / 111	140	10 / 111
Daihatsu					
Charade	87 →	110	10 / 111	105	10 / 111
Cuore	98 →	95	50 / 11	115	10 / 111
Grand Move	95 →	130	10 / 111	110/142	10/60/111/X
Sirion	04 →	170	20 / V	180	20 / V
Dodge					
Caliber	07 →	170	30 / IV	110	50 / 11
Fiat					
500	07 →	152	20 / V	121	10 / 111
500 C	09 →	155	20 / V	120	10 / 111
Bravo	07 →	140-161	30 / IV	125	10 / 111
Croma	05 →	160	20 / V	140	10 / 111
Doblò	00 → 10	143/188	20/60 / V/X	-	Blattfeder
Doblò	10 →	165	20 / V	132	10 / 111
Ducato	90 →	170	20 / V	-	Blattfeder
Grande Punto	05 → 09	140	10 / 111	120	10 / 111
Idea	03 →	145	30 / IV	122	10 / 111
Multipia	98 → 10	180	20 / V	130	10 / 111
Panda	03 → 11	100	10 / 111	120	10 / 111
Punto	03 →	152	20 / V	121	10 / 111
Scudo	96 → 07	180	20 / V	150	10 / 111
Scudo	07 →	175	20 / V	137	10 / 111
Sedici	06 →	129/156	20/60 / V/X	109	10 / 111
Stilo	01 → 08	144	30 / IV	120	10 / 111
Ulysse/Scudo	93 →	175	20 / V	135	10 / 111
Uno	90 →	145	10 / 111	125	10 / 111