

ANWENDUNGSÜBERSICHT MACPHERSON FEDERBEINSPANNER

					
Jahr	Front	Nr.	Heck	Nr.	
MINI					
Clubman	07 →	140	10 / III	108	10 / III
Cooper	01 → 06	160	20 / V	105	10 / III
Cooper	06 →	139	10 / III	105	10 / III
Cooper S	02 → 07	170	20 / V	107	10 / III
Cooper S	06 →	140	10 / III	105	10 / III
One	01 → 07	165	20 / V	105	10 / III
One	07 →	130	10 / III	110	10 / III
Mitsubishi					
ASX	4/10 →	174	20 / V	103	10 / III
Colt	04 → 12	120	10 / III	91/120	10/60 / III/X
Grandis	07 → 11	190	20 / V	130	10 / III
Lancer	88 →	175/145	20/60 / V/X	100	10 / III
Outlander	03 →	175	20 / V	105	10 / III
Pajero	00 →	130	10 / III	155	20 / V
NISSAN					
350 Z	03 → 09	105/115	10 / III	128	10 / III
Juke	10 →	146-162	20 / V	120	10 / III
Micra K12	02 → 10	140	10 / III	140	10 / III
Micra K13	5/10 →	114	10 / III	132	10 / III
Murano	07 →	190	20 / V	130	10 / III
Navara	07 →	110	50 / II	Blattfeder	-
Note	07 → 13	150	30 / IV	140	10 / III
NV400	11 →	195	NA	Blattfeder	-
Pathfinder	98 →	145/180	20/60 / V/X	155	20 / V
Patrol-Safari(R/L)	88 →	155	20/25* / V	175	20 / V
Pick-up	05 →	113	10 / III	Blattfeder	-
Pixo	09 →	137	10 / III	120	10 / III
Primastar	02 →	175	20 / V	175	20 / V
Primera III	02 →	143/175	20/60 / V/X	115	10 / III
Qashqai Right/Left	07 → 13	165	20/25* / V	145	10/25* / III
Teana J31	06 →	192	20 / V	127	10 / III
Tiida C11X	07 →	138	10 / III	133	10 / III
X-Trail	01 → 07	180	20 / V	144/170	20/60 / V/X
X-Trail	07 →	170	20 / V	150	20 / V
Opel					
Agila	00 → 07	100	10 / III	110	10 / III
Agila	07 →	121/156	20/60 / V/X	112	10 / III
Antara	06 →	160	20 / V	130	10 / III
Astra	04 → 10	145	30 / IV	145	30 / IV
Astra	10 →	159	20 / V	145	30 / IV
Corsa	06 →	140	10 / III	120	10 / III
Frontera	98 →	-	Torsions Feder	135	10 / III
Insignia	08 →	160	20 / V	136	10 / III
Meriva	03 → 6/10	130	10 / III	145	30 / IV
Meriva	6/10 →	142	10 / III	145	30 / IV
Signum	03 → 08	160	20 / V	135	10 / III
Tigra	94 → 00	130	10 / III	130	10 / III
Vectra C	03 → 08	140-160	60/20 / X/V	140	10 / III
Vivaro	07 →	145	20 / V	160	20 / V
Zafira	99 → 10	140	10 / III	150	20 / V
Zafira	11 →	146	20 / V	-	-
Peugeot					
107	05 →	135	10 / III	120	10 / III
1007	05 → 09	138/150	20/60 / V/X	115	10 / III
206/206+	98 → 07/12	160	20 / V	-	Torsionsfeder
206 SW	02 → 06	160	20 / V	-	Torsionsfeder
207	06 →	135-150	20/60 / V/X	125	10 / III
307	00 → 08	170	20 / V	115	10 / III
308	07 → 14	170	20 / V	120	10 / III
3008	09 →	153	20 / V	115	10 / III
407	04 → 10	135	10 / III	105	10 / III
4007	07 → 12	176	20 / V	130	10 / III
508	10 →	165	20 / V	107	10 / III
508 Hdi 180	10 →	136	10 / III	107	10 / III
5008	09 →	153	20 / V	130	10 / III
607	00 → 10	170	20 / V	170	20 / V

					
Jahr	Front	Nr.	Heck	Nr.	
807	02 → 10	180	20 / V	135	10 / III
Bipper Tepee	08 →	147	20 / V	120	10 / III
Bipper Van	09 →	143	20 / V	120	10 / III
Boxer	02 → 07	190	20 / V	-	Blattfeder
Expert	99 →	180	20 / V	135	10 / III
Expert Tepee	07 →	180	20 / V	137	10 / III
Partner	97 → 08	160	20 / V	-	Blattfeder
Partner	08 →	165	20 / V	-	Torsionsfeder
Partner Tepee	08 →	165	20 / V	130	10 / III
RCZ	10 →	150	20 / V	108	10 / III
Porsche					
911 Carrera	92 → 93	115	10 / III	100	10 / III
944	90 →	155	20 / V	-	Torsionsfeder
Carrera	07 →	170	20 / V	110	10 / III
Cayman	07 →	150	20 / V	140	10 / III
Renault					
Clio III	05 →	155	20 / V	140	10 / III
Clio Campus	06 → 12	147	20 / V	130	10 / III
Duster	10 →	138	10 / III	138	10 / III
Espace IV	02 →	170	20 / V	155	20 / V
Express	85 →	140	10 / III	-	Torsionsfeder
Grand Scenic	07 →	160	20 / V	100	10 / III
Kangoo	97 → 08	147	30 / IV	-	Torsionsfeder
Kangoo	08 →	155	20 / V	161	20 / V
Laguna	01 →	170	20 / V	125	10 / III
Master	97 →	150	20 / V	-	Torsionsfeder
Megane II	03 → 09	160	20/70 / V/XI	100	10 / III
Megane III	08 →	150	20/70 / V/XI	108	10 / III
Modus	04 → 12	155	20 / V	135	10 / III
Scenic	96 → 09	170	20 / V	-	Torsionsfeder
Scenic	09 →	160	20 / V	100	10 / III
Symbol	99 → 08	145	30 / IV	130	10 / III
Trafic	93 →	150	20 / V	-	Torsionsfeder
Trafic	02 →	150	20 / V	165	20 / V
Trafic	07 →	140	30 / IV	170	20 / V
Twingo	93 → 13	140	10 / III	100	10 / III
Twingo	14 →	140	95*	-	-
SAAB					
9-3	02 →	160	20 / V	140	10 / III
9-5	97 → 10	160	20 / V	120	10 / III
Seat					
Alhambra	96 → 10	180	20 / V	160	20 / V
Alhambra	10 →	143	30 / IV	119	10 / III
Altea	04 →	143/150	30 / IV	110	10 / III
Altea XL	06 →	140	10 / III	110	10 / III
Cordoba	96 → 09	140	10 / III	95	50 / II
Exeo	08 →	130	10 / III	133	10 / III
Ibiza	93 →	140	10 / III	95	50 / II
Leon	98 → 06	140	10 / III	110	10 / III
Leon	05 →	135	10 / III	112	10 / III
Leon TFSI	05 →	145	30 / IV	115	10 / III
Cupra R	11 →	140	10 / III	104	10 / III
Mii	91 → 09	143	30 / IV	115	10 / III
Skoda					
Citigo	11 →	138	10 / III	104	10 / III
Fabia	99 → 07	140	10 / III	100	10 / III
Fabia	07 →	135	10 / III	100	10 / III
Octavia II	04 → 12	145	30 / IV	110	10 / III
Octavia III	13 →	147	30 / IV	110	10 / III
Roomster	06 →	140	10 / III	110	10 / III
Superb	03 → 08	140	10 / III	150	20 / V
Superb	08 →	140	10 / III	115	10 / III
Yeti	09 →	148	20 / V	115	10 / III
Smart					
Forfour	04 → 06	120	10 / III	120	10 / III
Fortwo	04 →	105	10 / III	95	50 / II
Roadster	03 → 06	100	10 / III	100	10 / III

* Sonderbeschaffung

Konische Federn und Kugelfedern